




The PrecisePlace 2300/2400 Robot



Hardware Introduction and Reference Manual

Version 2.0.1, March 19, 2008
P/N: PP20-DI-00001

Document Content

The information contained herein is the property of Precise Automation Inc., and may not be copied, photocopied, reproduced, translated, or converted to any electronic or machine-readable form in whole or in part without the prior written approval of Precise Automation Inc. The information herein is subject to change without notice and should not be construed as a commitment by Precise Automation Inc. This information is periodically reviewed and revised. Precise Automation Inc., assumes no responsibility for any errors or omissions in this document.

Copyright © 2004-2008 by Precise Automation Inc. All rights reserved.

The Precise Logo is a registered trademark of Precise Automation Inc.

Trademarks

Guidance 3400, Guidance 3300, Guidance 3200, Guidance 2400, Guidance 1400, Guidance 1300, Guidance 1200, Guidance Controller, Guidance Development Environment, GDE, Guidance Development Suite, GDS, Guidance Dispense, Guidance Programming Language, GPL, Guidance System, PrecisePlace 1300, PrecisePlace 1400, PrecisePlace 2300, PrecisePlace 2400, PreciseFlex, PrecisePower 500, PrecisePower 2000, PreciseVision, RIO are either registered or trademarks of Precise Automation Inc., and may be registered in the United States or in other jurisdictions including internationally. Other product names, logos, designs, titles, words or phrases mentioned within this publication may be trademarks, service marks, or trade names of Precise Automation Inc. or other entities and may be registered in certain jurisdictions including internationally.

Any trademarks from other companies used in this publication are the property of those respective companies. In particular, Visual Basic, Visual Basic 6 and Visual Basic.NET are trademarks of Microsoft Inc.

Disclaimer

PRECISE AUTOMATION INC., MAKES NO WARRANTIES, EITHER EXPRESSLY OR IMPLIED, REGARDING THE DESCRIBED PRODUCTS, THEIR MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. THIS EXCLUSION OF IMPLIED WARRANTIES MAY NOT APPLY TO YOU. PLEASE SEE YOUR SALES AGREEMENT FOR YOUR SPECIFIC WARRANTY TERMS.

Precise Automation Inc.
727 Filip Road
Los Altos, California 94024
U.S.A.
www.preciseautomation.com

Warning Labels

The following warning and caution labels are utilized throughout this manual to convey critical information required for the safe and proper operation of the hardware and software. It is extremely important that all such labels are carefully read and complied with in full to prevent personal injury and damage to the equipment.

There are four levels of special alert notation used in this manual. In descending order of importance, they are:



DANGER: This indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury.



WARNING: This indicates a potentially hazardous situation, which, if not avoided, could result in serious injury or major damage to the equipment.



CAUTION: This indicates a situation, which, if not avoided, could result in minor injury or damage to the equipment.

NOTE: This provides supplementary information, emphasizes a point or procedure, or gives a tip for easier operation

Table Of Contents

Introduction to the Hardware	1
System Overview	1
System Description	1
System Diagram and Coordinate Systems	2
System Components	3
PrecisePlace 2300/2400 Robots	3
Mounting Plates and Risers	4
Theta Axis	4
Guidance 3400 Controller	5
Low Voltage Power Supply	5
Intelligent Motor Power Supply	6
Remote Front Panel, E-Stop Box and Manual Control Pendant	6
Remote IO Module	7
Machine Vision Software and Cameras	8
Machine Safety	9
Voltage and Power Considerations	9
Robot Back Cover	10
Safety and Agency Certifications	10
Standards Compliance and Agency Certifications	11
Moving Machine Safety	11
Installation Information	12
Environmental Specifications	12
Facilities Connections	12
System Dimensions	12
Mounting Instructions	14
Tool Mounting - PP2300	16
Tool Mounting - PP2400	17
Accessing the Controller and Power Supplies	18
Power Requirements	18
Emergency Stop	19
Hardware Reference	20
X-Axis Facilities Panel	20
Facilities Panel	20

Table Of Contents

Digital Input Signals	21
Digital Output Signals	23
Ethernet Interface	25
Remote Front Panel / MCP / E-Stop Interface	26
RS-232 Serial Interface	28
X and Y Axes	29
Z-Axis and Z-Axis IO PCB	30
Software Reference	35
Controller Software Extensions	35
Z-Axis General Digital Inputs and Outputs	35
Z-Axis Dedicated Digital Outputs	36
Service Procedures	37
Trouble Shooting	37
X & Y Linear Scale Cleaning and Replacement	37
Setting the Encoder Zero Positions	38
Removing the X-Axis Carriage	39
Installing and Adjusting the X-Axis Carriage	41
Removing and Installing the Y-Axis Carriage	41
Replacing the X and Y Motors	42
Replacing the X and Y Encoder Read Heads	42
Replacing the X and Y Axis Bearings	43
Replacing and Adjusting the Z Motor and Z-Axis Bearings	43
Appendix A: Product Specifications	45
PrecisePlace 2300/2400 Specifications	45
PrecisePlace 2300/2400 Environmental Specifications	46
Appendix B: FAQ	47
Frequently Asked Questions	47
Robot Hardware	47
Robot Software	48
Appendix C: Spare Parts Lists	49
Spare Parts Lists	49

Introduction to the Hardware

System Overview

System Description

The PrecisePlace Robot Series includes the PrecisePlace 2300, a three-axis XYZ Cartesian robot, and the PrecisePlace 2400, a four-axis XYZTheta Cartesian Robot. Both robots include an embedded Guidance 3400 four-axis motion controller, a PrecisePower 500 Intelligent Motor Power Supply, and a 24VDC power supply located inside the X-axis of the robot.

The X and Y axes of these robots are available in a number of different lengths with the X ranging from 500 mm to 1 M and the Y from 200 mm to 400 mm. The robots were designed as tabletop units and can carry a payload of up to 5 Kg in the three axis configuration or 3.5 Kg in the four axis configuration. These robots are low cost, extremely quiet and smooth, very reliable, and have excellent positioning repeatability. To achieve these results, the axes are powered by brushless DC motors. With these characteristics, these robots are ideal for automating applications in the Life Sciences, Medical Products, Semiconductor, and Electronics industries.

A number of communications and hardware interfaces are provided with the basic robot. These include an RS-232 serial interface, an Ethernet interface, a number of digital input and output lines, two analog input channels, and a remote front panel interface that provides IEC Category 3 safety signals. In addition, the robot can be purchased with several types of optional Precise peripherals. These include digital cameras, remote I/O, and a hardware manual control pendant.


The controller is programmed by means of a PC connected through Ethernet. There are three programming modes: a Digital IO (PLC) mode, an Embedded Language mode, and a PC Control mode. When programmed in the PLC or Embedded Language mode, the PC can be removed after programming is completed and the controller will operate standalone. The PC is required for operation in the PC Control mode.

In all modes of operation, the controller includes a web based operator interface. This interface is used for configuring the system, starting and stopping execution, and monitoring its operation. The web interface can be accessed locally using a browser or remotely via the Internet. This remote interface is of great benefit in system maintenance and debugging.

The optional machine vision system, "PreciseVision", can execute either in a PC connected through Ethernet, or (in the future) for less demanding applications, in the motion controller processor. PreciseVision requires cameras connected via Ethernet, allowing any processor on the network to obtain and process information from any camera on the network, and provide the results to any networked motion controller.

System Diagram and Coordinate Systems

The major elements of the three axes PrecisePlace robot and the orientation and origin of its World Cartesian coordinate system are shown in the diagram below.



The first axis of the robot moves in the World X direction and provides the mounting points for the robot. The primary electronic components are contained beneath the back cover for the X-axis. This includes the Guidance 3400 controller, the PrecisePower 500 Intelligent Motor Power Supply and the 24 VDC logic power supply. The Guidance controller not only controls the robot but also provides extensive hardware interfaces including Ethernet and digital and analog IO.



DANGER: The Guidance 3400, the PrecisePower Intelligent Motor Power Supply, and the 24VDC power supply are open frame electrical devices that have exposed unshielded high voltage pins, components and surfaces. In addition, the motor power supply provides 340VDC volts and takes about 2 minutes to bleed down after power is disconnected. **AC power to the robot must be disconnected prior to removal of the rear cover.**

When the X-carriage (and the Y-axis mounted to it) is closest to the Facilities Panel, the X-axis is approximately at its 0 position and at X=0 in the World coordinate system. As the X-carriage moves away from the Facilities Panel (to the right in the drawing above), both its joint position and the World X coordinate increase in value.

The second axis moves the tool of the robot along the Y-axis. When the Y-carriage (and the Z-axis mounted to it) is closest to the X-axis, the Y-axis is approximately at its 0 position and at Y=0 in the World coordinate system. As the Y-carriage moves away from the X-axis, both its joint position and the World Y coordinate increase in value.

The final linear axis moves the tool up and down in the Z direction. When the Z-axis is elevated as high as possible, it is approximately at its 0 position and at Z=0 in the World coordinate system. However,

when this axis moves down, while its joint position increases in value, its World Z coordinate becomes more negative in value.


The Z-axis carriage (the section connected to the Y-axis) includes an IO board that provides electrical and air services for both a 4th axis and end-of-arm tooling. A yellow lamp is mounted at the top of the Z-axis carriage cover and blinks at a rate of once per second to indicate that the controller is operational and at a rate of 4 times a second when power is being supplied to the motors.

The Z-axis includes a fail-safe brake. This brake must be released to move the Z-axis up and down manually. There is a manual brake release button on the rear of the Z-axis cover, near the E-chain. Depressing this button when 24VDC power is on will release the Z-axis brake while the button is depressed. It is not necessary for the control system to be operating for the brake release to work, the only requirement is providing 24VDC to the controller. Care should be taken to support the Z-axis when the brake release button is pushed, as the axis will fall due to gravity.


System Components

PrecisePlace 2300/2400 Robots

The PrecisePlace 2300 Robot (pictured below) is a 3-axis robot composed of an X-axis, with a stroke ranging from a minimum of 500 mm to a maximum of 1 M, a Y-axis with a stroke ranging from a minimum of 200 mm to a maximum of 400 mm, and a Z-axis with a stroke of 240mm. The Z-axis carriage contains a PCB (Z-Axis IO PCB) with connectors for driving a fourth motor/brake/encoder, connectors to route digital IO signals back to the controller, and an Ethernet connector that is routed back to the controller.



The PrecisePlace 2400 Robot (pictured below) is a 4-axis robot that is constructed by adding an optional Theta axis to the PrecisePlace 2300 Robot. The theta axis has a range-of-travel of +/- 270 degrees. The theta axis is utilized in applications where the Z angle of parts is not fixed and objects must be re-oriented as they are being handled.



Mounting Plates and Risers

Two shipping/mounting plates are provided with the PrecisePlace Robots. The Standard Mounting Plates can support the overhanging load of the robot without the need to bolt the robot to a table or other structure.

For connecting the robot to the Standard Mounting Plates or other mounting structures, M5 mounting holes are provided in the base of the robot on 75mm centers, spaced 100mm apart. The hole spacing allows the robot to be attached to a piece of structural T slot extrusion, for example 80/20 Inc. PN 25-5010 or PN 25-2576, by means of M5 bolts and T nuts. Risers and connectors in this same series of extrusion can be ordered from 80/20 Inc. and used to elevate the robot if desired.

Theta Axis

An optional Theta Axis may be purchased and attached to the Z-axis. The Theta Axis may be installed at the factory or in the field. This axis has +/- 270 degrees of rotation.

The Theta Axis has a 20 mm through hole (pictured below) that allows a camera mounted above on the Z-axis to view the tool tip. Alternately, cables can be routed through the hole in the cover and the axis to tooling and instrumentation attached to the Theta Axis.



Guidance 3400 Controller

The Guidance 3400 Controller is a four-axis general purpose motion controller that contains four motor drives and up to eight encoder inputs. It must be attached to a heat sink. In the PrecisePlace robots, the heat sink is provided by the X-axis extrusion. This controller includes local digital and analog IO, an RS232 serial port, 10/100 Mbit Ethernet ports and an interface for an optional front panel. These interfaces can be used to connect to an optional Precise Remote IO module, an optional hardware Manual Control Pendant and other peripherals.

In addition to the controller, a 500 watt PrecisePower Intelligent Motor Power Supply and the 125 watt 24VDC power supply are necessary to power the motors and electronics. All three of these components are housed in the robot's X-axis and are pictured in the previous [System Diagram and Coordinate Systems](#) section.

For detailed information on the controller including interfacing information, please see the *"Guidance Controller Hardware Introduction and Reference Manual"*.



DANGER: The Guidance 3400, the PrecisePower Intelligent Motor Power Supply, and the 24VDC power supply are open frame electrical devices that have exposed unshielded high voltage pins, components and surfaces. In addition, the motor power supply provides 340VDC volts and takes about 2 minutes to bleed down after power is disconnected. **AC power to the robot must be disconnected prior to removal of the rear cover.**

Low Voltage Power Supply

The Guidance 3400 requires 0.7 amps of 24 VDC for local power and 2 amps for IO power for a total of 2.7 amps. For applications using remote IO or Ethernet cameras, Precise recommends a total of 4 amps. This power is obtained from a 24 VDC power supply included with the robot.

The PrecisePlace Robots have an integrated 125-watt, 24 VDC Power Supply, Mean Well P/N PPS-125-24 that accepts a range of AC input from 90V to 264V. This power supply is shown mounted to the integrated X-axis heat sink in the [System Diagram and Coordinate Systems](#) section of this document.



DANGER: In addition to exposed high voltage pins and components, **the heat sinks on the 24VDC Power Supply are not grounded and expose high voltage levels.** AC power to the robot must be disconnected prior to accessing this unit.

Intelligent Motor Power Supply

The Guidance 3400 controller can accept motor power from 24 VDC to 320 VDC. The PrecisePlace robots include a 500-watt PrecisePower Intelligent Motor Power Supply. This device is auto-ranging with dual input ranges of 90 to 132 VAC and 180 to 264 VAC 50/60 Hz with a 320 VDC nominal output,

This intelligent power supply contains: a single relay for enabling and disabling motor power when commanded by the controller, built-in fuses, large value output filter capacitors to store deceleration energy for use when power is needed, and the ability to absorb line spikes.

This PrecisePower unit is shown mounted to the integrated X-axis heat sink in the [System Diagram and Coordinate Systems](#) section of this document.



DANGER: The PrecisePower Intelligent Motor Power Supply is an open frame electrical device that has exposed unshielded high voltage pins, components and surfaces. In addition, the power supply provides 340VDC volts and takes about 2 minutes to bleed down after power is disconnected. **AC power to the robot must be disconnected prior to accessing this unit.**

Remote Front Panel, E-Stop Box and Manual Control Pendant

For users that wish to have a hardware E-Stop button, Precise offers an E-Stop Box or a portable Hardware Manual Control Pendant that includes an E-Stop button. Either of these units can be plugged directly into the Remote Front Panel connector mounted on the robot's Facilities Panel. (The Facilities Panel is on the end of the X-axis.) Each of these units provides the hardware signals to permit power to be enabled and disabled.



In the future, Precise plans to offer a remote front panel that will contain a high power enable button, an auto/manual keyed selector switch, an E-Stop button, and a back panel connector for user E-Stops and interlocks.

NOTE: To enable motor power without an E-Stop Box, Hardware Manual Control Pendant or remote front panel, the jumper plug supplied with the system (pictured below) must be installed in the 25-pin Remote Front Panel connector.



For additional information on the signals provided on the Remote Front Panel connector, please see the Hardware Reference section of this manual.

Remote IO Module


For applications that require additional IO capability beyond the standard functions provided with every PrecisePlace robot, a Precise Remote IO (RIO) module may be purchased. The RIO interfaces to any PrecisePlace robot and its embedded Guidance Controller via 10/100 Mb Ethernet and requires 24 VDC power. Up to 4 RIO's can be connected to a controller.

The basic RIO includes: 32 isolated digital input signals, 32 isolated digital output signals and one RS-232 serial line. An enhanced version of the RIO adds 4 analog input signals, a second RS-232 port and one RS-422/485 serial port. In addition, expansion boards will soon be offered that cost effectively add additional isolated digital inputs and outputs in groups of 32 each to the basic RIO.

The Enhanced RIO module is pictured below.



WARNING: The RIO contains unshielded 24 VDC signals and pins. This product is intended to be mounted in a cabinet or machine chassis that is not accessible when power is turned on.




Machine Vision Software and Cameras

The Guidance 3000 Series controllers support the PreciseVision machine vision system. This is a vision software package that can run either on a PC for higher performance applications, or in the motion controller processor for simple applications (future development).

Cameras must be connected via Ethernet. Vendors such as DALSA offer a variety of Ethernet machine vision cameras. In addition, vendors such as Pleora offer RS 170 to Ethernet converter boxes (iPORT PT-1000 ANL1/2/E) that allow a large variety of standard cameras to be connected to the Guidance network.

To simplify mounting a camera on the robot either to eliminate a separate camera mount or to permit higher magnification to be used in several different regions of the workspace, Precise offers a special camera mounting kit. The Precise Arm-Mounting Camera Option permits a DALSA Genie Series Ethernet Camera and a ring light to be attached to the robot's Z axis.

This kit includes a camera and ring light power supply that is installed in the Z-axis IO board, a camera bracket, a ring light with a mounting bracket, an Ethernet cable to connect the camera to the robot's Ethernet harness, and power cables for connecting the camera and ring light to the Z-axis IO board power supply. The Arm-Mounted Camera Option is typically factory installed, but can be installed in the field if necessary.



Machine Safety

Voltage and Power Considerations

The Guidance 3400 requires two DC power supplies, a 24 VDC power supply for the processor and user IO, and a separate motor power supply. The motor power supply must provide a voltage to the controller between 24 VDC and 320 VDC. For the PrecisePlace robots, the PrecisePower Intelligent Motor Power Supply delivers 320 VDC to the controller although the motors will operate correctly at 160 VDC as well.



DANGER: The Guidance 3400, the PrecisePower Intelligent Motor Power Supply, and the 24 VDC power supply are all open frame electrical devices that contain unshielded high voltage pins, components and surfaces. These products are intended to be mounted in a cabinet or machine chassis that is not accessible when AC line power is turned on. In the PrecisePlace robots, these units are mounted beneath the robot's back cover.

The PrecisePlace robots include a 500-watt auto-ranging PrecisePower Intelligent Motor Power Supply with a dual input range of 90 to 132 VAC and 180 to 264 VAC 50/60 Hz and a 320 VDC output. This motor power supply contains a relay for enabling and disabling motor power from the controller.

The PrecisePower Intelligent Motor Power Supply limits inrush current to 6 Amps. It is protected against voltage surge to 2000 volts by means of MOV's at the line input. Transient over voltage ($< 50 \mu s$) may not exceed 2000 V phase to ground, as per EN61800-31996. It is protected against over current by two 6.3 amp, 250V time lag fuses, Wickman PN 1811630000.

The Precise controller can monitor motor power through its datalogging function. Intermittent power dropouts can be detected by setting a trigger in the data logger which can record and time-stamp power fluctuations.

Robot Back Cover


In the PrecisePlace robots, the Guidance 3400 and its power supplies are mounted in the X extrusion under a cover that should be in place whenever power is applied to the robot.



DANGER: The PrecisePower Intelligent Motor Power Supply is an open frame supply that provides 340VDC volts and takes about 2 minutes to bleed down after power is disconnected. The 24VDC power supply is also an open frame supply with high voltages terminals and heat sink surfaces exposed when the robot cover is removed. **The robot should not be operated without the back cover in place.**



DANGER: The surfaces, connectors, and leads pictured in Red below indicate exposed elements of the Guidance 3400 controller that carry motor power signals. These signals levels are 340 VDC.



Safety and Agency Certifications

Precise systems can include computer-controlled mechanisms that are capable of moving at high speeds and exerting considerable force. Like all robot and motion systems, and most industrial equipment, they must be treated with respect by the user and the operator.

This manual should be read by all personnel who operate or maintain Precise systems, or who work within or near the work cell.

We recommend that you read the American National Standard for Industrial Robot Systems – Safety Requirements, published by the Robotic Industries Association (RIA) in cooperation with the American National Standards Institute. The publication, ANSI/RIA R15.06, contains guidelines for robot system installation, safeguarding, maintenance, testing, startup, and operator training. We also recommend that you read the International Standard IEC 204 or the European Standard EN 60204, Safety of Machinery – Electrical Equipment of Machines, and ISO 10218 (EN 775), Manipulating Industrial Robots – Safety, particularly if the country of use requires a CE-certified installation.

Standards Compliance and Agency Certifications

The PrecisePlace robots are intended for use with other equipment and are considered a subassembly rather than a complete piece of equipment on their own. They meet the requirements of these standards:

- EN 61000-4-2 Electrostatic Discharge (8KV air, 6KV contact)
- EN 61000-4-3 Radiated Electromagnetic Field Immunity (3V/m, 27-500MHz)
- EN 61000-4-4 Electrical Fast Transient/Burst Immunity (2KV)
- EN 61000-4-5 Surge Immunity Test (1KV differential, 2KV common mode)
- EN 61000-4-6 Conducted Disturbances Immunity (RF: 150KHz – 80MHz)
- EN 50081-2 Electromagnetic Compatibility General Emissions Standard

To maintain compliance with the above standards the controller must be installed and used in accordance with the regulations of the standards, and in accordance with the instructions in this user's guide.

In addition to the above standards, the Guidance 3400 has been designed to comply with the following agency certification requirements (certification of compliance with these standards is currently in process):

- TUV
- UL
- CSA
- ANSI/RIA R15.06 Safety Standard

Moving Machine Safety

The PrecisePlace robots can operate in Manual Control Mode, in which an operator directly controls the motion of the robot, or Computer Control Mode in which the robot operation is automatic. Manual Control Mode is often used to teach locations in the robot workspace. The robot's speed is limited in Manual Control Mode to a maximum of 250mm per second for safety. While the PrecisePlace is a light-duty robot that can only apply approximately 100 Newtons of force, it is very important for operators to keep their hands, arms and especially their head out of the robot's operating volume.

In Computer Mode the robot can move at speeds up to 2000mm per second. During Computer Mode Operation it is strongly recommended that operators be prevented from entering the robot work volume by safety barriers that are interlocked to the E-stop circuitry. Please refer to the ANSI/RIA R15.06 Safety Standard for Industrial Robots for information on recommended safe operating practices and enclosure design for robots of various sizes and payloads.

Installation Information


Environmental Specifications

The PrecisePlace robots must be installed in a clean, non-condensing environment. Please see the [Environmental Specifications](#) in Appendix A for specific environmental limits.

Facilities Connections



The right (Facilities) end cap of the X-Axis extrusion includes the following:

- System AC input power receptacle
- Lighted AC on/off power switch
- Two 4mm OD pneumatic tubing fittings (one-touch type tube insertion)
- Connectors for controller input and output signals



System Dimensions


Both top and right views are shown below. All dimensions are in millimeters.




Mounting Instructions

PrecisePlace robots must be attached to a rigid surface that can withstand lateral forces of 200 Newtons without moving or vibrating. The robot is shipped with Standard Mounting Plates that are attached to the X extrusion with M5 by 25mm screws. M5 mounting holes are provided in the base of the robot on 75mm centers, spaced along the bottom of the X-axis as illustrated in the drawing below.


It is recommended that there be a mounting support at least every 300mm under the robot.




**X-axis mounting hole pattern every 100mm along X-axis
75mm BC for M5 by 25mm SHCS
Remove X cover to install mounting screws**



The Standard Mounting Plates that are shipped with the robot are shown below. These plates can be detached by removing the X-axis cover. Removal of the end caps is not required. See the [Hardware Reference X and Y Axis](#) section for instructions on removing the cover.




The 75mm hole spacing allows the robot to be attached to structural T slot extrusion. For example, 80/20 Inc. supplies this type of extrusion as PN 25-5010 or PN 25-2576, which can be attached to the robot using M5 bolts and T nuts. Risers and connectors in this same series of extrusion can be ordered from 80/20 Inc. and used to elevate the robot. For risers up to 115mm in height, this extrusion can be cut off and M5 screws up to 140mm long (available from Misumi) can be run directly thru the M5 holes into M5 tapped holes on the mounting surface. The M5 holes in the extrusion may need to be drilled out to M5.2 or so for screw clearance.




Tool Mounting - PP2300

The PrecisePlace 2300 Z-Axis has been designed to permit tooling to be easily attached. The face of the Z-Axis has two vertical slots that can be used to mount an optional Theta Axis, syringe operators, grippers, cameras, or other user items. Two additional slots are also available on the edges of this axis. Precise supplies four M4 nuts for these slots. A commercial compatible M4 nut is the Misumi HNTTBS5-4.


To facilitate electrical interfacing to user tooling, digital I/O and Ethernet signals are available on a "Z-Axis IO PCB" that is located under the Z-axis motor cover (this is described in a later section). For pneumatic tools, air lines with connections (4mm OD, 75 PSI maximum) are also brought out to the Z-axis. These lines are routed internally through the robot and exit at pneumatic fittings on the X-Axis right end cap.




Shown below are the details of the mounting slots of the Z-Axis as viewed from above. All dimensions are in units of millimeters.



Tool Mounting - PP2400



The Theta Axis that is a component of the PrecisePlace 2400 is shown mounted on the Z-Axis using the T-slots. The dimensions of the overall Theta assembly and its tooling flange are shown below.



Accessing the Controller and Power Supplies

Although most of the controller interface signals are exposed on the Facilities Panel on the right end cap of the X-axis, there are times when it is necessary to access either the robot's controller or its power supplies. To access these components, the rear cover of the robot must be removed.



DANGER: The Guidance 3400, the PrecisePower Intelligent Motor Power Supply, and the 24VDC power supply are open frame electrical devices that have exposed unshielded high voltage pins, components and surfaces. In addition, the motor power supply provides 340VDC volts and takes about 2 minutes to bleed down after power is disconnected. **AC power to the robot must be disconnected prior to removal of the rear cover.**

For later models of the PrecisePlace robot, the rear cover can be detached by removing four screws that secure the cover to the end caps of the X-axis. For earlier models, removal of the rear cover requires detachment of the plain X-axis end cap of the robot that is opposite the Facilities Panel end cap. To remove the plain X-axis end cap, first push the Y-axis all the way to its end of travel near the Facilities Panel end cap. Then detach the plain end cap by removing the M4 Socket Head Cap screws that are retaining it. Once the plain end cap is removed, the back cover may be detached.

Once the rear cover is removed, the connectors and jumpers on the top surface of the controller, which are utilized for hardware configuration and interfacing to external equipment, and the power supplies will be exposed. Please note that the Ethernet, digital IO and RS232 signals are brought out to connectors on the Facilities Panel. However there are hardware jumpers and some additional controller signal connectors, including the analog IO, optional DAC signals, etc that can only be accessed by removing the back cover.

Please see the *Guidance 3000/2000 Controller, Hardware Introduction and Reference Manual* for detailed information on hardware configuration and interfacing the controller using the various input and output ports such as those for digital and analog I/O. Also, please refer to the *Guidance System Setup and Operation Quick Start Guide* for information on configuring the PC and instructions on operating the robot. Both of these manuals are available in PDF format and are also contained in the *Precise Documentation Library*.

Prior to replacing the back cover of the robot, please read the remaining sections on installing the robot since there are some special configuration options that also require access to the components mounted below the back cover.

Power Requirements

The PrecisePlace robots contain auto-ranging power supplies that operate between 90 to 132 and 180 to 264 VAC, 50 or 60Hz. The robots are equipped with an IEC electrical socket that accepts country specific electrical cords. Power requirements vary with the robot duty cycle, but do not exceed 500 watts RMS.

Normally, the robot is factory configured to operate its motors at 320 VDC, which can be automatically generated from either of the dual AC input ranges. However, the robot's motors can be optionally operated at 160 VDC. The PrecisePower 500 Intelligent Motor Power Supply can be manually configured to supply 160 VDC if necessary, providing that the input power is 90 to 132 VAC.

At the right end of the PrecisePower Intelligent Motor Power Supply, there are three sets of jumper pins labeled "90-132V", "Auto", and "180-264V". A jumper must be placed across one of these sets of pins to select the power supply operating mode. The power supply includes a voltage doubling circuit. This circuit is activated when the jumper is placed across the "90-132V" pins, disabled when the "180-264V" jumper is installed, and automatically activated when a jumper is placed across the "Auto" mode pins. The output voltage range for each jumper is illustrated in the following table. The PrecisePower unit is normally shipped with the jumper on the "Auto" setting to allow the robot to operate worldwide with the factory setting.

AC input	90-132V Jumper	Auto Jumper	180-264V Jumper
90 to 132 VAC	253-372 VDC	253-372 VDC	127-186 VDC
180 to 264 VAC	Invalid setting	253-372 VDC	253-372 VDC

Emergency Stop

It is often desirable to wire a hardware Emergency Stop Button to the controller. This button may be wired in series with other emergency stop contacts. The E-stop signals are available in the Remote Front Panel 25-pin DSub connector that is mounted on the X-axis Facilities Panel. Please see the Hardware Reference section of this manual for detailed information on the Remote Front Panel signals.


Precise sells an emergency stop button in a plastic enclosure. This E-Stop Box comes with a cable and connector that directly plugs into the Remote Front Panel connector. Alternately, you can also purchase a Precise Manual Control Pendant. The Pendant has an integrated E-Stop button and provides a convenient means for manually jogging the robot via a portable hand-held device.

Hardware Reference

X-Axis Facilities Panel

Facilities Panel

The right end-cap of the X-axis is the robot's Facilities Panel. This contains plugs and connectors for AC power, pneumatic air lines and electrical interfaces.



The AC input connector is an IEC power cord connector that mates with standard cables that can provide a wide variety of AC power plugs. The supported input voltage ranges are 90 to 132 VAC and 180 to 264 VAC, auto selecting, and the permitted input frequency is 50-60 Hz. The AC power to the robot is controlled by a green backlit On/Off Switch.

To simplify interfacing, most of the electrical interfaces provided by the robot's embedded Guidance Controller are available on the Facilities Panel. These include:

- [Digital input signals](#)
- [Digital output signals](#)
- [Ethernet port](#)
- [Remote Front Panel / MCP / E-Stop](#)
- [RS-232 serial interface](#)

Each of these interfaces is described in detail in the following sections. In addition, the robot's controller, which is mounted under the X-axis rear cover, may contain additional interfaces (e.g. analog inputs or

outputs). Please refer to the *Guidance Controller, Hardware Introduction and Reference Manual* for additional information.



DANGER: The Guidance 3400, the PrecisePower Intelligent Motor Power Supply, and the 24 VDC power supply are all open frame electrical devices that contain unshielded high voltage pins, components and surfaces. In addition, the motor power supply provides 340VDC volts and takes about 2 minutes to bleed down after power is disconnected. **The main AC power should always be disconnected before the back cover of the X-axis is removed.**


As a convenience for pneumatically powered user tooling, two air lines are routed through the interior of the robot. At the Facilities Panel, these are presented as two fittings. The other end of these lines exit at the Z-axis E-Chain. When using these lines, clean, dry external air should be provided.



CAUTION: The maximum air pressure that can be conveyed by the air lines through the robot is **75 PSI**. Applying a pressure exceeding this level may disconnect interior connections or damage fittings or hoses. If a higher pressure is required, an external air line should be utilized.


Digital Input Signals

The PrecisePlace robot provides 12 general purpose optically isolated digital input signals at the Facilities Panel (in addition to those signals that are available at the Z-Axis IO Board). These lines are accessed in a single DB15 connector.




DB15 Female

These input signals can be configured as "sinking" or "sourcing". If an input signal is configured as "sinking", the external equipment must pull its input high to 5VDC to 24VDC to indicate a logical high value or must allow it to float to no voltage for a logical low.



As shipped from the factory, the input signals are configured as "sourcing", i.e. the external equipment must pull a signal input pin to ground to indicate a logical high and must let the line float high to 24VDC to signal a logical low value.



Inputs can be configured as sinking or sourcing in groups of 4 signals. To configure groups of input signals, the X-axis rear cover must be removed and jumpers on the Guidance Controller must be changed. For more information on configuring the jumpers, please see the *Guidance Controller, Hardware Introduction and Reference Manual*.



DANGER: The Guidance 3400, the PrecisePower Intelligent Motor Power Supply, and the 24 VDC power supply are all open frame electrical devices that contain unshielded high voltage pins, components and surfaces. In addition, the motor power supply provides 340VDC volts and takes about 2 minutes to bleed down after power is disconnected. **The main AC power should always be disconnected before the back cover of the X-axis is removed.**

The pin out for the Digital Input Connector is described in the following table.

Pin	Description
1	GND
2	Digital Input 2
3	Digital Input 4
4	Digital Input 6
5	Digital Input 8
6	Digital Input 10
7	Digital Input 12
8	GND
9	Digital Input 1
10	Digital Input 3
11	Digital Input 5
12	Digital Input 7
13	Digital Input 9
14	Digital Input 11
15	24 VDC
Interface Panel Connector Part No	DB15 Female Connector
User Plug Part No	DB15 Male Plug


Digital Output Signals

The PrecisePlace robot provides 8 general purpose optically isolated digital output signals at the Facilities Panel (in addition to those signals that are available at the Z-Axis IO Board). These lines are accessed in a single DB15 connector.




These output signals can be configured as "sinking" or "sourcing". ***As shipped from the factory, the output signals are configured as "sinking"***, i.e. the external equipment must provide a 5VDC to 24VDC pull up voltage on an output pin and the controller pulls this pin to ground when the signal is asserted as true.

SINKING DIGITAL OUTPUT



Alternately, the output signals can be configured as "sourcing", i.e. the external equipment must pull down an output pin to ground and the controller pulls this pin to 24VDC when the signal is asserted as true.

SOURCING DIGITAL OUTPUT



Outputs can be individually configured as sinking or sourcing signals. To configure the output signals, the X-axis rear cover must be removed and jumpers on the Guidance Controller must be changed. For more information on configuring the jumpers, please see the *Guidance Controller, Hardware Introduction and Reference Manual*.



DANGER: The Guidance 3400, the PrecisePower Intelligent Motor Power Supply, and the 24 VDC power supply are all open frame electrical devices that contain unshielded high voltage pins, components and surfaces. In addition, the motor power supply provides 340VDC volts and takes about 2 minutes to bleed down after power is disconnected. **The main AC power should always be disconnected before the back cover of the X-axis is removed.**

The pin out for the Digital Output Connector is described in the following table.

Pin	Description
1	Digital Output 1 - This output signal can drive 500mA of current whereas Outputs 2-8 can only drive 100mA. Due

	to this higher drive level, even when this output is off, a small amount of current leaks. This leakage can cause some devices that are connected to this signal to always indicate that this output is on. If this occurs, a small drainage resistor should be tied to this signal.
2	Digital Output 3
3	24 VDC
4	Digital Output 5
5	Digital Output 7
6	Not used
7	Not used
8	Not used
9	Digital Output 2
10	Digital Output 4
11	GND
12	Digital Output 6
13	Digital Output 8
14	Not used
15	Not used
Interface Panel Connector Part No	DB15 Female Connector
User Plug Part No	DB15 Male Plug

Ethernet Interface

PrecisePlace robots are equipped with communication interface boards (MCIM's) that include an Ethernet switch that implements two 10/100 Mbit Ethernet ports. This capability was designed to permit the controller to be interfaced to multiple Ethernet devices such as other Precise controllers or robots, remote I/O units and Ethernet cameras. The Ethernet switch automatically detects the sense of each connection, so either straight-thru or cross-over cables can be used to connect the controller to any other Ethernet device.

Due to limited space on the X-Axis Facilities Panel, only one of the two Ethernet ports is available via an external RJ45 connector. This external Ethernet port is typically used to interface the robot to a PC



As a convenience for Ethernet devices that are mounted on the Z-axis of the robot, the second Ethernet port is connected to an Ethernet cable that is routed through the interior of the robot. One end of this cable is plugged into the robot controller's Ethernet switch and the other end is under the cover for the Z-axis motor. Any device that is plugged into this cable, such as an Ethernet camera mounted on the Z-

axis, can also communicate with units that are plugged into the RJ45 on the Facilities Panel. So, a PC that is connected to the Ethernet plug on the Facilities Panel can communicate with the robot's controller as well as receive images from an arm-mounted camera.

If a camera is mounted in the workcell, an external Ethernet switch must be added to connect these cameras and the robot to a PC.

See the *Setup and Operation Quick Start Guide* for instructions on setting the IP address for the controller.

Remote Front Panel / MCP / E-Stop Interface

The remote front panel interface includes all of the signals necessary to implement a fully compliant EC Category 3 Safety front panel that includes a Manual Control Pendant. In particular, this connector provides signals (including redundancy as necessary) for implementing an E-Stop circuit, an auto/manual switch, a high power "on" button with a high power "on" indicator lamp, and a RS-232 interface for a Manual Control Pendant (MCP). These signals are provided in a DB25 female connector mounted on the robot's Facilities Panel.



In the future, Precise will offer a Remote Front Panel option that plugs into this connector. Alternatively, customers can develop their own custom front panels (please see the section on "Safety Circuits For Remote Front Panel" in the *Controller Hardware Manual* for a suggested design). Or, if your application does not require a fully compliant Category 3 front panel, the robot can be operated without a front panel or with a Precise hardware MCP or a Precise E-Stop box. Both the Precise MCP and the E-Stop box can plug directly into the Remote Front Panel connector and provide a hardware emergency stop capability via the connector's redundant E-stop signals.

When a front panel, hardware MCP or E-Stop box is not utilized, the following pins on the front panel connector must be jumpered in order for the controller to operate properly. (The robot is shipped with a jumper plug that satisfies these requirements.)

1-14, 2-15, 3-16, 4-17, 5-18, 6-19, 7-20

If a Manual Control Pendant is not connected to the secondary RS-232 port provided in this connector, this serial interface can be accessed via a GPL procedure as device `"/dev/com2"` for general communications purposes. Please note that unlike the primary serial interface, **THIS SECONDARY SERIAL INTERFACE DOES NOT SUPPORT FLOW CONTROL.**

Pin	Description
1	Auto/Manual 2 (If no front panel or Auto mode, connect to pin 14). Input signal that is high to indicate that the system is being operated in a fully

	automatic mode or low or open for manual operation. This is normally controlled by a key switch on the Remote Front Panel. The Auto/Manual signal must be daisy chained to all amps on a controller network.
2	Auto/Manual 1 (If no front panel or Auto mode, connect to pin 15). Redundant Auto/Manual input signal.
3	ESTOP_L 2 (If no front panel or E-Stop not asserted, connect to pin 16). Input signal that is low or open to indicate that a hardware E-Stop condition has been asserted by any source. Set high if no E-Stop condition is asserted. The controller hardware will not permit motor power to be enabled when an E-Stop condition exists.
4	ESTOP_L 1 (If no front panel or E-Stop not asserted, connect to pin 17). Redundant ESTOP input signal.
5	External ESTOP_L (If no front panel or not an External ESTOP, connect to pin 18). Diagnostic input signal that is low when an E-Stop is generated from an external source. This allows the System Software to display different error messages to alert the operator as to the source of the E-Stop condition.
6	High Power Lamp Fail (If no front panel, jumper to pin 19). Input signal that is set high or open if the Remote Front Panel lamp, which indicates when motor power is enabled, has failed. When this signal is high, motor power cannot be enabled.
7	High Power Enable (If no front panel, jumper to pin 20). Input signal that must transition from low to high during the EC Category 3 power enable sequence to request that motor power be enabled. This is normally connected to a momentary contact "Enable power" push button on the Remote Front Panel.
8	Not used
9	MCP RXD. RS-232 receiver serial line from the Manual Control Pendant or external device.
10	5 VDC
11	Not used
12	Not used
13	Not used
14	24 VDC
15	24 VDC
16	Force ESTOP_L. Output signal that, when low, indicates that the Remote Front Panel should force ESTOP_L 1 and ESTOP_L 2 to be asserted (low). The System Software toggles this signal low at startup to verify that the ESTOP_L 1, ESTOP_L 2, and External ESTOP circuits are properly working. The System Software also uses this as a means for asserting a hardware E-Stop condition during normal operation. This signal is normally held high.
17	Force ESTOP_L. Redundant Force ESTOP_L output signal.
18	Force ESTOP_L. Redundant Force ESTOP_L output signal.
19	GND
20	GND
21	High Power Status. Output signal that is asserted (high) when high power to the motor is enabled. This is typically connected to a relay that

	turns on the High Power Lamp in the Remote Front Panel.
22	MCP TXD. RS-232 transmitter serial line to the Manual Control Pendant or external device.
23	5 VDC
24	Not used
25	Not used
Interface Panel Connector Part No	DB25 Female Connector
User Plug Part No	DB25 Male Plug

RS-232 Serial Interface

The PrecisePlace robot includes a standard RS-232 serial line equipped with hardware or software flow control. This port can be used to communicate to the system serial console or can be connected to external equipment for general communication purposes. When used for general communications, this port is referenced as device "/dev/com1" within the Guidance Programming Language (GPL).

The connector for this interface is a female DB9 that has pin assignments compatible with standard PC "com" ports. A straight through DB9 to DB9 cable be used to connect the Guidance System to a PC.



The following table defines the pin assignments for this connector.

Pin	Description
1	Not used
2	TXD - Transmit data
3	RXD - Receive data
4	Not used
5	GND
6	Not used
7	CTS - Clear to send for hardware flow control
8	RTS - Request to send for hardware flow control
9	Not used
Interface Panel Connector Part No	DB9 Female Connector
User Plug Part No	DB9 Male Plug

X and Y Axes

The X and Y axes are each composed of an extrusion, a motor carriage, a linear encoder, linear bearings, covers, and end caps. Each motor carriage employs a traction drive and bearings (that are lubricated for the life of the product) to move along an extrusion. Each motor includes a rotary encoder for motor commutation. Separate linear encoders attached to the X and Y extrusions are used to determine the position of these axes. These linear encoders contain a periodic calibration code that is read when the axis is moved just a few millimeters during the robot "homing" process.

Each motor is attached to a friction wheel that is spring loaded against an extrusion. The spring tension is adjusted by means of a M4 Socket Head Cap "Tension Screw", shown below. Nominal tension is set at 5 complete turns of this screw for the X-axis and 4 turns for the Y-axis beyond the point where the friction wheel first touches the drive surface and the springs begins to compress. This provides about 100 Newtons of traction on the Y-axis and 160 Newtons of traction on the X-axis before the drive slips. Under normal operation, motor thrust should not exceed 80 Newtons peak on the Y-axis and 120 Newtons peak on the X-axis. After extended periods of time, it may be necessary to increase the spring load by one or two additional turns to compensate for friction wheel wear. This will be application dependent, but typically should not occur before 10,000 hours of operation. If the drive does slip, high power will be turned off automatically, and the robot will stop. In this case, the robot does not lose the homing reference, however, high power must be re-enabled. To continue from that point either a lower acceleration must be employed or the spring load may be adjusted. Commanding accelerations that result in more than these traction forces may cause slipping. These traction forces will allow about 0.6G of acceleration for the X-axis, and about 1G of acceleration for the Y-axis with a payload of 3kg.

The robot's wire and air harness is routed through the motor carriages. At each carriage, the motor and encoder signals for that carriage are terminated and all other lines are continued to the next axis.


The X-axis motor carriage and tension screw are shown below. The Y-axis carriage is very similar but only mates to a single linear bearing. To access either the X or Y carriage, its top cover must first be removed.

To remove the cover for either the X-axis or Y-axis to gain access to the motor carriage, perform the following steps:

1. Slide the carriage to one end of its travel.
2. Remove four screws in the end caps that attach the top cover extrusion to the end caps.
3. Slide the cover to one side to release the edge of the tape seal on the opposite side. The grooves in the cover that capture the tape seals are cut deep for this purpose.
4. Slide the cover in the opposite direction over the tape seal and extract the cover.



DANGER: All of the motors for the PrecisePlace robot are operated at 320 VDC. As such, the motor wires present a high risk and unshielded pins and conductors should not be touched unless the main AC power to the robot is first disconnected.



Z-Axis and Z-Axis IO PCB


The Z-axis is composed of a motor carriage, an extrusion, end caps, a sliding cover, and an IO Printed Circuit Board ("ZIO2"). The Z motion drive consists of a timing belt reduction and main drive belt attached to the Z stage. The Z motor includes a fail-safe brake that can be manually released by pressing a button on the side of the ZIO2 Board.

The ZIO2 PCB serves as a connector board for motor and encoder signals and provides 8 isolated user digital input and 8 isolated user digital output signals. It also supports a robot power status light, and an optional power supply and connectors for the arm mounted camera and ring light option. For I/O control, this board is connected to the robot's controller by an RS485 serial line that allows the I/O to be scanned with a nominal period of 4 milliseconds.

The following drawing illustrates the position of each of the key connectors on the board.



DANGER: A motor connector that provides a bus voltage of 320 VDC is positioned near the ZIO2. As such, accessing this board represents a high risk and should only be performed when the main AC power to the robot is disconnected.




In the following table, each of the connectors is briefly described. For application interfaces, such as the digital output signals, pin assignments are described in detail in subsequent tables.


Connector	Description
Brake Release Button / Output	The Brake Release Output is wired to the fail-safe brake on the Z-axis motor. This brake prevents the axis from falling when power is off. Normally, this brake is automatically controlled by the system software. If the Brake Release Button is pressed, the brake can be manually released so long as power is provided to the robot's controller.
Camera Power / Light Power	If the optional Arm Mounted Camera Option is purchased, these connectors provide power to the camera and the camera's ring light. The camera power is always available whenever the robot's controller is powered on. The ring light power can be turned on and off via software control.
Digital Inputs / Digital Outputs	These provide 8 optically isolated user input and 8 optically isolated user output signals. These signals are available to interface to tooling and sensors mounted on the end of the robot. These signals are described in detail below.
LED1 (Activity / Error)	Green - Blinks fast (about 10Hz) when the ZIO2 is not communicating with the robot's controller. Blinks slowly (about 1Hz) during normal communication. Red - Off at initial power-up and during normal communications. On if communications is lost after being established.
LED2 (Camera light)	Green - Tracks the state of the camera ring light power output. Red - No currently used.
Power Status Light	This connects to an LED mounted in the top of the Z-axis cover. When controller is first powered on, the LED will blink approximately once per second. When motor power is enabled, the blink rate will increase to 4 times per second.
RS485 Daisy Chain	The RS485 interface is a multi-drop high speed serial interface that permits the robot controller to operate the digital input and

	output signals on the ZIO2 board. Two identical connectors are provided to permit the RS485 signals to be daisy-chained to other RS485 devices mounted on the end of the robot.
Theta Encoder To Harness/Motor	These are two pass through connectors that interface the Theta (4th) axis encoder to the appropriate signals in the robot harness. The Theta encoder internal harness connector should be plugged into the "To Harness" board connector. If a Theta axis is present, its encoder should be plugged into the "To Motor" connector.
Z Encoder To Harness/Motor	These are two pass through connectors that interface the Z (3rd) axis encoder to the appropriate signals in the robot harness. The Z-axis encoder internal harness connector should be plugged into the "To Harness" board connector. The Z-axis encoder should be plugged into the "To Motor" connector.


The 8 isolated digital input and 8 isolated digital output signals provided on the ZIO2 are intended for interfacing to tooling and sensors mounted on the end of the robot or for other general application needs. These DIO signals are in addition to those available on the X-axis Facilities Panel of the robot. These signals are provided in two 16 pin connectors:



The 8 digital input signals are configured as "sinking". That is, the external equipment must pull an input high to 5VDC to 24VDC to indicate a logical high value or must allow it to float to no voltage for a logical low. For convenience, 24VDC is supplied on the digital input signal connector.



The 8 digital output signals are configured as "sourcing". That is, the external equipment must pull down an output pin to ground and the ZIO2 pulls this pin to 24VDC when the signal is asserted as true. For convenience, ground pins are supplied on the digital output signal connector.



The pin assignments for these two connectors are defined in the following tables along with the part number for the required plugs.

Pin	Description
1	Digital Input 1
2	Digital Input 5
3	Digital Input 2
4	Digital Input 6
5	Digital Input 3
6	Digital Input 7
7	Digital Input 4
8	Digital Input 8
9 to 16	24 VDC
User Plug Part No	Amp 746285-3 or Molex 22-55-2161 or Molex 90142-0016. For the Molex plugs, use Molex pins 16-02-0102 and Molex crimp tool 63811-1000.
High Flex Cable	A high flex cable should be used to ensure long life. We recommend 3M Round Conductor High Flex Life Flat Cable, 28 AWG stranded, PVC, 3319/16 or Amphenol Spectra-Flex high flex life flat cable 843-191-2811-016.

Pin	Description
1	Digital Output 1
2	Digital Output 5
3	Digital Output 2
4	Digital Output 6

PrecisePlace_2300_2400_Robot

5	Digital Output 3
6	Digital Output 7
7	Digital Output 4
8	Digital Output 8
9 to 16	Ground
User Plug Part No	Amp 746285-3 or Molex 22-55-2161 or Molex 90142-0016. For the Molex plugs, use Molex pins 16-02-0102 and Molex crimp tool 63811-1000.
High Flex Cable	A high flex cable should be used to ensure long life. We recommend 3M Round Conductor High Flex Life Flat Cable, 28 AWG stranded, PVC, 3319/16 or Amphenol Spectra-Flex high flex life flat cable 843-191-2811-016.

There are two four-pin connectors that provide power for a camera and camera ring light if the Arm Mounted Camera option is installed.



The pin assignments for these connectors are defined in the following table along with the part number for the required plug type.

Pin	Description
1	12VDC, 1.25A total current is shared between two connectors.
2	Ground
3	9VDC only on Ring Light Connector. Enabled and disabled via a dedicated system IO signal. 1A total current is shared between two connectors.
4	Ground
User Plug Part No	AMP 794617-4. Use an AMP 91501-1 hand crimp tool and AMP 794610-3 sockets for wiring to the plug.

Software Reference

Controller Software Extensions

This section discusses extensions to the standard Guidance Controller software that are specific to the PrecisePlace Robot.

Z-Axis General Digital Inputs and Outputs

The Z-Axis IO (ZIO2) PCB adds 8 general optically isolated digital outputs and 8 general optically isolated digital inputs to the standard digital I/O found on the Guidance Controller. Like the other general inputs and outputs, they can be assigned for various control purposes during system setup, or they can be used directly by a GPL procedure.

Unlike the controller's standard digital I/O that are directly accessed on demand, these I/O are scanned by the controller. The scanning period is nominally 4 milliseconds, so your application must be able to handle a delay of up to 4 milliseconds for signal changes to propagate through the system.

The additional I/O signals are shown in the table below:

Signal Number	I/O	Label	Description
33	O		Z I/O board output 1
34	O		Z I/O board output 2
35	O		Z I/O board output 3
36	O		Z I/O board output 4
37	O		Z I/O board output 5
38	O		Z I/O board output 6
39	O		Z I/O board output 7
40	O		Z I/O board output 8
10033	I		Z I/O board input 1
10034	I		Z I/O board input 2
10035	I		Z I/O board input 3
10036	I		Z I/O board input 4
10037	I		Z I/O board input 5
10038	I		Z I/O board input 6
10039	I		Z I/O board input 7
10040	I		Z I/O board input 8

Z-Axis Dedicated Digital Outputs

The Z-Axis IO (ZIO2) PCB adds two dedicated digital outputs to the standard dedicated signals found in the Guidance Controller, as shown in the table below.

Users normally do not need to modify the setting of the Z-axis status lamp (IO 8040) since the standard robot software typically manages this signal.

If the robot includes the Arm Mounted Camera Option, the Camera Light Power is controlled by a dedicated digital output signal. This signal can be manually altered via the web Robot ZIO Panel or under program control via the GPL SIGNAL.DIO instruction.

Signal Number	I/O	Label	Description
8039	O		Camera Light. If the Arm Mounted Camera option is installed, set to 1 to turn on the Camera Light. Set to 0 to turn off the Camera Light.
8040	O		Z-axis status lamp. Set to 1 to turn on the lamp. Normally parameter "Power State DOUT" (DataID 235) is set to this signal number so that the Z-axis lamp displays the robot power state.

Service Procedures

Trouble Shooting

Symptom	Recommended Action
System error message generated	
"Amplifier Fault"	Slow down the robot. Check harness and motor for shorts.
"Encoder quadrature error"	For errors on the X or Y axis (joints 1 or 2): Clean linear scale with denatured alcohol
	Replace the motor/encoder
"Excessive dual encoder slippage"	Tighten M4 Tension screw one turn, lower acceleration
"Illegal zero index"	See "Encoder quadrature error"
"Missing zero index"	See "Encoder quadrature error"
"Motor duty cycle exceeded"	Reduce speed or acceleration of robot
"Soft Envelope Error"	Make sure robot not pressing against surface
Physical or audible problem	
Brown streaks on linear bearings	Clean with alcohol and add grease to bearing blocks. This should not be required sooner than 20,000 hours of run time.
"Clunking" when reversing direction	Remove carriage. Check motor suspension plate mounting screws. Screws should be tight enough to allow motor spring tension to work, but not loose. If loose, apply Loctite and re-tighten.
Mechanical noise from carriage	Check carriage bearings for failure

X & Y Linear Scale Cleaning and Replacement

Excessive dust or oil on the linear encoder scales can cause Quadrature or Zero Index Errors. The scales can be cleaned with a lint-free cloth and denatured alcohol. The scales can usually be cleaned without removing them.

NOTE: Do not use rubbing alcohol as this typically contains 30% water and can leave a film as it evaporates.

The scales can be removed and replaced by removing the vinyl spline retaining the scale in the extrusion. A new scale may be cut to length with a pair of scissors. When a scale is replaced, care must be taken

that the emulsion side is facing the back side of the robot on the X-axis (the controller side) and facing the side of the Y-axis opposite the Z-axis. The emulsion side is the side from which the Precise Automation label can be read correctly. It is opposite the stainless steel band side. So in the case of the X-axis, you should be able to read the Precise Automation label when standing behind the robot by the controller and, in the case of the Y-axis, when standing on the side facing the Z-axis. In both cases, the vinyl spline should be pressing against the side with the stainless steel band.

To install an encoder scale, move the carriage to one end of its travel and slide the scale into the groove in the extrusion and through the carriage. You may need to wiggle the scale a bit as it goes through the carriage to get the scale through the encoder read head gap. Once the scale is lying in the encoder groove, position the scale so that the read head does not run off the end of the scale at either extreme of travel of the carriage. Then install the spline by pressing it down into the groove on the non-emulsion side of the scale.

NOTE: Press the spline down vertically, don't stretch it by running your thumb down the spline – this can cause the scale to creep.

The spline can be installed in several pieces. Typically the carriage is moved to one end of travel and a length of spline installed in the groove that is not under the carriage, then the carriage is moved down and a second piece of spline installed in the groove that was under the carriage.

When a linear scale is removed, it is necessary to re-establish the encoder zero positions in order for the homing sequence to work properly. See the section below for instructions on executing the Cal_PP program to set the encoder zero positions.

Setting the Encoder Zero Positions

Cal_PP is a service program that must be run to set the zero positions of the X and Y axis linear scales, and the Z and Theta motor encoders. The zero positions must be re-established if the X or Y axis linear scales or the Z or Theta motors are replaced.


Cal_PP is supplied on the *Guidance Controller System Software CD*. To run Cal_PP, the controller must be configured to run GPL programs and Cal_PP must be loaded into the controller's memory (See the *Guidance System Setup and Operation, Quick Start Guide*).

The following describes the procedure for defining the zero positions of the PrecisePlace robot axes using Cal_PP.

1. Enable power to the robot's controller, but do not turn on power to the motors.
This procedure should be executed with motor power disabled.
2. Load Cal_PP into the controller's memory using either the Guidance Development Environment (GDE) or the web Operator Control Panel.
3. Manually move the X, Y and Z axes to a position more than one zero index away from their lower hard stop limits. As you face the robot with the power cord on the right, the X-axis lower stop limit is to the far right, the Y-axis lower stop limit is with the axis fully retracted, and the Z-axis lower stop limit is with the axis all of the way up. For the X and Y axes, a zero index distance is approximately 10 mm. For the Z-axis, a zero index distance is approximately 25 mm. Positioning

an axis further away will not cause a problem but a shorter distance may cause this procedure to fail.

4. Manually move the X, Y and Z axes to their lower hard stop limits. This motion will ensure that at least one zero index for each of these three axes is detected by the controller. The final location of each axis will define the physical position that will correspond to their lower hard stop positions.
5. If your robot is equipped with a Theta axis, rotate this axis to either hard stop and then move this axis to its mid-range position. Insert an M4 X 6mm shoulder screw through the notch in the theta flange into the theta frame to accurately locate the theta flange. This screw is supplied with the theta axis.



6. Execute the Cal_PP program using GDE or the web Operator Control Panel. This program will execute in just a few seconds. During this time, it will compute the data required by the homing operation and will save it on the flash disk. **While this program is executing, several pop-up displays will appear either within GDE or on the Operator Control Panel.** Please follow the provided instructions and correct any errors that may occur.
7. Enable the power to the robot's motors and execute the homing sequence. The new encoder zero positions will take effect when the robot is homed.

The zero position for each of the robot's axes will now be defined and the data required by the homing operation will be stored in the controller's flash disk.

Removing the X-Axis Carriage

In order to change the motor or bearings on the X carriage, it is necessary to remove the X carriage. This can be done without removing the Z-axis and Y carriage from the Y-axis.


Prior to performing this procedure, you should obtain four 15mm bearing ball retainer blocks from Precise Automation customer service.



DANGER: All of the motors for the PrecisePlace robot are operated at 320 VDC. As such, the motor wires present a high risk and unshielded pins and conductors should not be touched unless the main AC power to the robot is first disconnected.

To remove the X carriage, perform the following steps:

1. Remove the X and Y covers by removing four M4 screws from the end caps. (For detailed instructions, please consult [Hardware Reference > X and Y Axes](#).)
2. Remove the two M3 screws holding the tape seal tension bars against both the X carriage and the Y carriages.



3. Remove the tape seals from the tension bars.
4. Remove the left X end cap (opposite the power cable) by removing four M4 SHC machine screws.
5. Remove the Y end cap closest to the X-axis.
6. Place a support under the Y-axis so it does not drop when it is detached from the X-axis.
7. Remove the Y-axis from the X carriage by removing four M4 X 12mm Socket Head Cap Screws.
8. Slide the Y-axis forward away from the X-axis taking up slack in the harness service loop in the Y-axis.
9. Remove the X-axis carriage cover by removing four M3 X 6mm Button Head Screws.
10. Unplug the X motor and X encoder from the harness.
11. Remove the harness clamp where the harness enters the X carriage by removing two M3 X 12mm Socket Head Cap Screws.
12. Remove the air transfer harness clamp from the X carriage by removing two M3 X 10mm Socket Head Cap Screws.
13. Lift the harness out of the X carriage.
14. Pick up the entire Y, Z and Theta axis assembly and lay it down in front of the X-axis with the end of the Y-axis close to the left end of the X-axis. This will allow the harness to lay flat as it comes out of the end of the X-axis.
15. Slide the X carriage out of the left end of the X-axis, inserting four 15mm bearing ball retainer blocks into the bearings as the carriage bearing blocks slide off the linear rails

Installing and Adjusting the X-Axis Carriage

To install the X-axis Carriage into the X-axis, perform the following procedure.



DANGER: All of the motors for the PrecisePlace robot are operated at 320 VDC. As such, the motor wires present a high risk and unshielded pins and conductors should not be touched unless the main AC power to the robot is first disconnected.

1. In preparation for installing the X-carriage into the X-axis, first verify that the M4 Socket Head Cap “Tension Screw” (illustrated in [Hardware Reference > X and Y Axes](#)) is backed out enough so that the friction wheel is not in compression when the carriage is installed. The X motor should be able to slide against the end of the adjustment slot in the motor mounting tab and the tension screw should not project more than 2 mm beyond the back of the motor tension flange.
2. Slide the X carriage into the X-axis, removing the bearing retainer blocks as the carriage slides onto the linear rails.
3. When the carriage is installed and the motor friction wheel is not engaged, it should be possible to push the carriage along the axis with between 5 to 10 Newtons (1 to 2 lbs) of force. If the force is higher than this, it is likely the bearings are not aligned properly.
4. To engage the traction drive, the motor tension adjusting screw should be tightened until the friction wheel touches the drive surface and the spring starts to compress, and then turned 5 more full turns.

Once the robot has been reassembled, the tension adjustment and friction can be checked by turning on the robot and pushing on the X-axis quickly (less than 2 seconds) with a force gauge with a force of 120 Newtons or 24lbs. The X motor should resist this peak force for a period of 2 seconds, and then a “Duty Cycle Exceeded” Error will be generated and power should be automatically turned off. If the friction wheel slips before 120 Newtons of force is reached, the tension screw should be tightened one half turn at a time.

Removing and Installing the Y-Axis Carriage

In order to remove the Y-axis carriage, perform the following procedure.

Note, prior to performing this procedure, you should obtain two 24mm bearing ball retainer blocks from Precise Automation customer service.



DANGER: All of the motors for the PrecisePlace robot are operated at 320 VDC. As such, the motor wires present a high risk and unshielded pins and conductors should not be touched unless the main AC power to the robot is first disconnected.

1. Remove the Z-axis cover.
2. Unplug the Z-axis cables.

3. Remove the three M4 Screws attaching the Z-axis to the Y-axis carriage and detach the Z-axis.
4. Remove the Y-axis cover. (For detailed instructions, please consult [Hardware Reference > X and Y Axes.](#))
5. Remove the two M3 screws holding the tape seal tension bars against the Y carriage. (See [Removing the X-Axis Carriage](#) for an illustration.)
6. Remove the tape seals from the tension bars.
7. Remove the Y end cap opposite the X-axis.
8. Remove the harness from the Y carriage in a manner similar to the X carriage.
9. Slide the Y carriage out the end of the Y-axis, inserting two 24mm bearing ball retainer blocks into the bearings as the carriage bearing blocks slide off the linear rails.

Installing the Y carriage is similar to installing the X carriage, however the Y force is typically 80 Newtons.

Replacing the X and Y Motors

The X and Y motors are similar. The X motor is a 200 watt motor and Y motor is a 100 watt motor. These motors can be replaced by first removing the appropriate carriage and then removing the four M5 bolts attaching the motor to the motor suspension plate.




DANGER: All of the motors for the PrecisePlace robot are operated at 320 VDC. As such, the motor wires present a high risk and unshielded pins and conductors should not be touched unless the main AC power to the robot is first disconnected.

Replacing the X and Y Encoder Read Heads

The X and Y axes use a dual encoder system with one encoder read head on the motor carriage for position information and a second encoder/read head in the motor for motor commutation and control. These two encoder read heads each has a cable terminated in a 5-pin connector. These two connectors plug into a 10-pin header mounted on a PCB that is attached to the motor carriage. The motor read head connector plugs into the header pins furthest away from the PCB and closest to the motor. The linear encoder read head connector plugs into the pins closest to the surface of the PCB. Pin 1 for both 5-pin connectors (denoted by small arrows on the connectors) is plugged into the pins closest to the encoder end of the motor.



DANGER: All of the motors for the PrecisePlace robot are operated at 320 VDC. As such, the motor wires present a high risk and unshielded pins and conductors should not be touched unless the main AC power to the robot is first disconnected.



Replacing the X and Y Axis Bearings

The X-axis includes two 15mm square bearing rails mounted on the extrusion and four bearing blocks attached to the carriage. The rails are secured by M4 screws and T nuts. In the unlikely event that it is necessary to replace these bearings rails, perform the following procedure.

1. Remove the X carriage. (See the section on [Removing the X-Carriage](#) for details.)
2. Remove the linear bearings.
3. Remove the bearing blocks from the carriage.
4. Install new bearing blocks on the carriage with the bearing blocks pressed against the reference bosses on the bearing mounting flanges. This sets the bearing spacing and ensures the bearing blocks are parallel to each other.
5. Install the linear rails with the linear rail at the front of the robot (farthest from the control section) pressed against the reference boss to align it. The linear rails have a small arrow engraved on the top surface that indicates the reference edge of the linear rail. This is the edge that should be pressed against the reference boss.
6. Set the spacing of the second rail by sliding the carriage along the rails and tightening the second rail.

When properly installed and aligned, there should be no binding as the carriage slides along the rails.

The Y bearings run on a single rail which rests on a reference boss and are replaced in a similar manner.


Replacing and Adjusting the Z Motor and Z-Axis Bearings

The Z-axis is driven by timing belts. The Z motor assembly includes a motor, brake, encoder and timing belt drive pulley in a single unit. It can be replaced by loosening the motor bracket retaining screws,


loosening the timing belt tensioning screw and removing four M5 screws from the motor tensioning bracket.



DANGER: All of the motors for the PrecisePlace robot are operated at 320 VDC. As such, the motor wires present a high risk and unshielded pins and conductors should not be touched unless the main AC power to the robot is first disconnected.



The Z drive main belt tension can be adjusted by tighten two tensioning screws in the upper Z end cap. If the Z belt or Z bearing needs to be replaced, these screws must be removed. Then the upper Z end cap must be removed. At this point the Z bearing block and Z linear rail may be removed and replaced.



Appendix A: Product Specifications

PrecisePlace 2300/2400 Specifications

General Specification	Range
Range of Motion & Resolution	
X-Axis	Configurations from 500 mm to 1000 mm
Y-Axis	Configurations from 200 mm to 400 mm
Z-Axis	240 mm
Optional Theta Axis	+/- 270 degrees
Resolution	+/- 0.008 mm in X, Y, and Z standard +/- 0.001 mm in X, Y, and Z available with high resolution option
Repeatability	+/- 0.050 mm, 68 – 78 degrees F, limited by aluminum structure expansion
Performance and Payload	
Maximum acceleration	0.6G
Maximum speed	2000 mm/sec
Z Force	Continuous upwards Z force - 60N Continuous downwards Z force - 60N
Payload	PrecisePlace 2300: 5 kg PrecisePlace 2400: 3.5 kg
Controller	<i>AVAILABLE GUIDANCE CONTROLLERS:</i> Guidance 3400 (G3X0-EA-03400), Guidance 3404 (G3X0-EA-03404), Guidance 3406 (G3X0-EA-03406)
Interfaces	
General Communications	RS-232 channel, Ethernet ports, remote front panel
Digital I/O Channels	12 optically isolated inputs, 8 optically isolated outputs included on controller. Additional 8 isolated inputs and 8 isolated outputs provided on the Z-axis. Remote I/O also available.
Analog I/O Channels	2 analog inputs included 4 or 6 analog outputs optionally available
Pneumatic Lines	Two air lines, each 75 PSI maximum, provided at Z-axis drive and routed internally to fittings on the X-axis end cap.
Operator Interface	Web based operator interface supports local or remote control via browser connected to embedded web server.
Programming Interface	Three methods available: DIO MotionBlocks (PLC), embedded Guidance Programming Language (standalone), PC controlled over Ethernet via Windows

PrecisePlace_2300_2400_Robot

	DLL.
Required Power	Dual range: 90 to 132 VAC and 180 to 264 VAC, auto selecting, 50-60 Hz, 500 watts maximum
Weight	30 kg typical, will vary with size

PrecisePlace 2300/2400 Environmental Specifications

The PrecisePlace Robots must be installed in a clean, non-condensing environment with the following specifications:

General Specification	Range & Features
Ambient temperature	5°C to 40°C
Storage and shipment temperature	-25°C to +55°C
Humidity range	5 to 90%, non-condensing
Altitude	Up to 3000m

Appendix B: FAQ

Frequently Asked Questions

This section contains a compilation of frequently asked questions related to PrecisePlace 2300/2400 robots.

A. Robot Hardware

1. [How do you operate the robot when plugged into a GFI circuit?](#)

A. Robot Software


1. [How do you switch between a 3 and 4 axis configuration?](#)

Robot Hardware

How do you operate the robot when plugged into a GFI circuit?

In almost all situations, to power a PrecisePlace robot, all that is required is that the robot be plugged into a standard AC service. However, if you plug the robot into an electrical service that has a GFI (Ground Fault Interrupter) circuit, the GFI may be tripped when motor power is enabled. If this occurs, the problem can be easily remedied by plugging the robot into an isolation transformer that is capable of supplying at least 500 VA and plugging the isolation transformer into the GFI circuit.

Isolation transformers of this type are readily available and cost approximately \$100-\$150. For example, the following transformer, a Hammond 171E is available from www.mouser.com as part number 546-171E for \$130.



Robot Software

How do you switch between a 3 and 4 axis configuration?

The Theta axis for the PrecisePlace robot is designed to be easily added or removed from the robot in the field. You may need to do this if you find that your application unexpectedly needs to accommodate part rotations or if you need additional Z payload capability and the theta is not required.

The procedure for mechanically installing or removing the Theta axis is described elsewhere. This document presents instructions for reconfiguring the software for this change.

The system software that is already loaded into your controller will operate either the PrecisePlace 2300 or 2400 robot. To change the robot type, you simply need to provide new configuration information in the form of the "Configuration and Parameter Database Disk Files", i.e. the PAC files.

Before superceding the configuration files in a controller, it is strongly recommended that you first either copy the controller's configuration to a host computer or use the web interface to create a backup set of configuration files in the flash disk.

When you are ready to load the new configuration files to your controller, please perform the following procedure.

1. Obtain the PAC files for the new robot configuration. These can normally be found on the "Guidance Controller System Software CD" that came with your system. The files are located in the PAC folder in the subfolder with the name of the robot that you wish to configure. Alternately, you can contact Precise for the appropriate files.
2. Start up GPL on your Guidance controller.
3. Connect to the controller using a web browser and login.
4. Click on the tab labeled "Utilities" .
5. Click on the words "Backup and Restore" in the left-hand panel.
6. Click the button "Start File Manager" to open a FTP window. This should open the /flash/ folder.
7. Double click the "config" folder to display its contents.
8. Open the folder that you identified in Step #1 that contains the new configuration files.
9. Drag the "**robot01.pac**" and the "**calib01.pac**" file from the host computer folder to the controller's FTP window and drop them.
10. Wait until the copy operation is completed.

WARNING: Always wait 10 seconds after writing to the flash before you power down the controller, otherwise, you may corrupt the flash disk.

11. Close the FTP window and return to the "Backup and restore" panel.
12. Restart the controller to put the new configuration information into effect.

At this point, your robot will be operational, but the zero positions for each of the axes will be incorrect. To set the zero positions, please see the "PrecisePlace 2300/2400 Robot, Hardware Introduction and Reference Manual" for instructions on executing the Cal_PP procedure.

Appendix C: Spare Parts Lists

Spare Parts Lists

Description	Part Number
805mm Linear Encoder Scale	0000-MC-E0005 + PP10-MC-X0013 + PP10-MC-X0010
Linear Encoder Read Head Assembly	PP1A-MC-E0001 + 0000-EC-H0036 + 0000-EC-H0037 (qty 5) + 0000-HC-W0001 (25 inches)
832 Theta Encoder Disk	PP14-MC-E0001
832 Theta Encoder Read Head Assembly	0000-MC-E0010 + 0000-EC-H0036 + 0000-EC-H0037 (qty 5) + 0000-HC-W0001 (25 inches)
X Motor Assembly	PP10-MC-D0011 + PP1A-MA-00008 + 0000-EC-H0184 (qty 4) + 0000-EC-H0047
Y Motor Assembly	PP10-MC-D0012 + PP1A-MA-00007 + 0000-EC-H0184 (qty 4) + 0000-EC-H0047
Z Motor Assembly	PP10-MC-D0013 + PP20-MC-X0000 + 0000-EC-H0184 (qty 6) + 0000-EC-H0047
Theta Motor Assembly	PP10-MC-D0014 + PP1A-MA-00007 + 0000-EC-H0184 (qty 6) + 0000-EC-H0047
15mm X Carriage Bearing Block + Bearing Ball Retainer Block	PP11-MC-B0000
15mm X Linear Bearing Rail (specify stroke)	PP11-MC-B0001
24mm Y Bearing Block + Bearing Ball Retainer Block + Linear Bearing Rail	PP11-MC-B0002
Z 24mm Carriage Bearing Block + Linear Bearing Rail	PP11-MC-B0003
G3410A Controller (G3410A, G3414A or G3416A)	G3X0-EA-A3410, G3X0-EA-A3414 or G3X0-EA-A3416
500 Wt PrecisePower Intelligent Motor Power Supply	PS10-EA-00500
125 Wt 24VDC Power Supply	PS10-EP-00125
ZIO2 Board	PP13-EA-00001
Dual Encoder Buffer Board	PP1A-EA-00001
Fuse, PrecisePower Motor Power Supply	Wickman PN 1811630000
Z-axis T nuts, M4	Misumi PN HNTTBS5-4
Mounting Plate, Extended (no tip version)	PP10-MC-M0006

